

T-Series Hydraulic Bolt Tensioner

USER MANUAL

| | | | | | | | |
|------------------------------|---|------------------------|---|-----------------------|----|-----------------------|----|
| Health & Safety Instructions | 4 | Operating Instructions | 8 | Maintenance & Storage | 27 | Technical Information | 38 |
|------------------------------|---|------------------------|---|-----------------------|----|-----------------------|----|



FOREWORD

Thank you for choosing Boltight equipment.

Before using the equipment you are advised to study this manual carefully.

Boltight Limited is an ISO 9001:2015 company and our bolt tensioning equipment has been designed to comply with the European Pressure Equipment Directive and the UK Pressure Equipment Regulations and is CE marked and UKCA marked respectively. The pressures and forces involved with the use of this equipment are high and it is therefore imperative that users of the equipment read and understand the operating manual, paying particular attention to the safety information in Section 1.

COPYRIGHT STATEMENT & DISCLAIMER

This Health & Safety, Operating and Maintenance Manual has been prepared by Boltight Limited. All material in this manual is the property of Boltight Limited and is subject to Copyright. No part of this manual may be copied or reproduced without prior written consent.

Please note that the scope of this document covers the safety, operation and maintenance instructions concerned with the equipment supplied ONLY. Safe handling, usage and storage of this equipment on customer applications and installations is the responsibility of the customer. This document should only be considered a part of the customer's wider procedure for installation of plant and therefore Boltight Limited cannot accept any responsibility for any actions arising as a result of misuse of this equipment.

The contents of this manual may periodically be subject to alteration. Boltight Limited reserves the right to alter or modify this manual without prior notification.

Further copies of this manual can be downloaded from the website www.nord-lock.com/Boltight

CONTENTS

| | |
|---|-----------|
| SECTION 1 – HEALTH & SAFETY INSTRUCTIONS | 4 |
| 1.1 Safety notes | 4 |
| 1.2 European pressure equipment directive | 5 |
| 1.3 Using quick connectors | 5 |
| 1.4 Hoses | 6 |
| 1.5 Hydraulic bolt tensioning tools | 7 |
| 1.6 Personal protective equipment (PPE) | 7 |
| SECTION 2 – OPERATING INSTRUCTIONS | 8 |
| 2.1 Recommended practices | 8 |
| 2.2 Main component parts | 9 |
| 2.3 Fatigue life | 9 |
| 2.4 Tensioning a bolt | 10 |
| 2.5 De-tensioning a bolt | 18 |
| 2.6 Simultaneous bolt tensioning | 10 |
| SECTION 3 – MAINTENANCE & STORAGE | 27 |
| 3.1 Storage | 27 |
| 3.2 Changing the seals | 27 |
| 3.3 Parts Breakdown | 28 |
| 3.4 Changing the inner piston seal | 29 |
| 3.5 Changing the outer piston seal | 31 |
| 3.6 Fitting the piston | 32 |
| 3.7 Energising the seals | 34 |
| 3.8 Fitting a quick connector (without a bonded seal) | 35 |
| 3.9 Fitting a quick connector (with a bonded seal) | 36 |
| 3.10 Removing and fitting the bridge | 37 |
| SECTION 4 – TECHNICAL INFORMATION | 38 |
| 4.1 Oil pressure calculations | 38 |
| 4.2 Pressure load graphs | 38 |
| 4.3 Tool specification and dimensions | 39 |
| 4.4 Technical information – Imperial bolt sizes | 40 |
| 4.5 Technical information – Metric bolt sizes | 45 |

SECTION 1 – HEALTH & SAFETY INSTRUCTIONS

1.1 SAFETY NOTES

Hydraulic bolt tensioning tools are very powerful and capable of inducing very high bolt stresses. This equipment will give many years of safe tensioning when used in accordance with these instructions.

Anyone using hydraulic bolt tensioning equipment must be properly trained to use the equipment and must take adequate steps to ensure their own safety and the health and safety of others where bolt tensioning operations are being performed. Boltight can offer training courses either at its UK base or on site anywhere in the world.

Please read the manual before attempting to use the equipment. Do not use the equipment if you are not already an experienced user of hydraulic bolt tensioning equipment. Your attention is particularly drawn to the notes in **RED**.

When using hydraulic bolt tensioners, loads of many hundreds of tonnes or even thousands of tonnes can be induced. If the bolt material is incorrect or faulty or the tool is incorrectly installed, the broken bolt could be propelled at high speed along the axis of the bolt. This is a very rare occurrence. If there is a failure, anyone standing near the bolt tensioning tool or in line with the axis of the bolt during the tensioning operation will suffer critical, possibly fatal, injury. It is therefore essential that anyone operating this equipment is properly trained and takes every precaution to ensure that nobody is allowed to stand, work or stray near to or in line with the axis of any hydraulic bolt tensioning tool during the bolt tensioning operation.

At no time should anyone allow any part of their body to be positioned over the puller of a bolt tensioning tool, whilst the pressure is rising or when it is pressurised. In the case of studbolts with nuts at each end it is important that nobody stands in line with the long axis of the bolt at either end during the tensioning operation.

Do not approach a bolt tensioning tool whilst it is being pressurised. Remember that a damaged bolt or tool is most likely to fail at this critical time. When the operating pressure has been reached, approach a pressurised bolt tensioning tool only for as long as it takes to turn the permanent nut always keeping away from the axis of the bolt and the puller.

Bolt Tensioning tools **MUST** always be used with a hydraulic pump which has a pressure limiting device. Always check that the pump stall pressure is set at or below, the maximum working pressure for the tool being used.

Clear all personnel from the area where the bolt tensioning operation is to be performed. Position the pump a safe distance away from the bolt tensioning tools. Set up barriers and warning signs, or make other adequate arrangements to prevent unauthorised personnel from accidentally straying into the bolt tensioning area.

Never leave a pressurised bolt tensioning tool unattended. Keep the bolt tensioning tools under pressure for the minimum time necessary to complete the bolt tightening job. The tools should only be used as a bolt tensioning tool. **DO NOT** use the tools as hydraulic jacks or for any other purpose.

Take care when handling the tools. Large tools may be heavy and require the use of lifting equipment. The bridge and load cell of the larger tools are not held together. The load cell and bridge are easily taken apart.

Do not try to tighten a leaking hydraulic connection when it is under pressure. First release the pressure then repair the leak.

1.2 EUROPEAN PRESSURE EQUIPMENT DIRECTIVE

The T Series range of hydraulic bolt tensioners are designed to operate at pressures up to 1500 bar with Group 2 liquid (hydraulic oil ISO 32 or ISO 46) with a volume less than 10 litres. This equipment aligns with:

- Category 1:- 2014/68/EU European Pressure Equipment Directive
- Category 1:- UK Pressure Equipment (Safety) Regulations 2016.

Under these regulations the equipment must therefore:

- a) be safe;
- b) meet the essential safety requirements covering design, manufacture and testing;
- c) be accompanied by adequate instructions for use;
- d) be marked to identify the manufacturer and CE marked and the UKCA mark respectively.

The regulations call for pressure equipment to be pressure tested at 1.43 times the maximum pressure. However the regulations recognise that in some cases this may be harmful or impractical. Due to the very high bolt stresses developed, it is impractical to pressure test the equipment at 1.43 times the maximum pressure. It would also be harmful to the seals if the equipment was tested at these pressures. All equipment has been tested to 1.1 times the maximum pressure where appropriate and a test certificate has been issued.

1.3 USING QUICK CONNECTORS

DO NOT pressurize the connectors when they are disconnected.

Check that there is no pressure in the system before attempting to connect or disconnect the couplings.

To connect the quick connect coupling and nipple, first check there is no pressure in the system. Pull back the shroud by hand and push the coupling onto the nipple. When together, release the shroud which will spring back to connect the coupling and nipple together. The coupling should now be locked using the safety locking sleeve (SLS). To disconnect, again check there is no pressure in the system. Pull back the shroud by hand, and pull the coupling and nipple apart. Once apart release the shroud.



Pull the shroud into the retract position



Insert the nipple into the coupling whilst the shroud is in the retract position



Allow the shroud to spring back into the forward position



Check the red line is not visible – if red line is visible the connection is not safe to use



To close the safety locking sleeve (SLS) push the shroud forward to the back of the collar and rotate – release to lock



This image shows the SLS in the locked position – this joint is now safe to use

1.4 HOSES

Boltight supply flexible hydraulic hoses which have a small plastic core tube surrounded by multiple high tensile steel spiral windings. The outside of the hose is molded with a coloured plastic coating. Most hoses also have a clear plastic cover which provides additional protection against damage when in use. Each hose is identified with a serial number. All hoses are pressure tested and test certificates are issued.

Three types of hose are available which are identified by the colour of the molded plastic coating beneath the clear plastic cover. The maximum working pressure for the hose is sometimes marked on the outside of the coloured plastic coating; however this is the working pressure of the hose **ONLY** and not the hose **ASSEMBLY**.

The maximum working pressure of a hose assembly is often limited by the pressure rating of the quick connect couplings and/or the fittings on the end of the hose. Although the hose may be capable of operating at higher pressures the limit you must observe is shown below along with the minimum bend radius.

| COLOUR | MAX WORKING PRESSURE | MIN BEND RADIUS |
|--------|----------------------|-----------------|
| GREEN | 1000 bar | 95 mm |
| BLUE | 1500 bar | 130 mm |
| RED | 2500 bar | 200 mm |



Hoses are fitted with self sealing quick connect couplings at one or both ends.

YOU MUST OBSERVE THE FOLLOWING HEALTH & SAFETY INSTRUCTIONS WHEN USING HYDRAULIC HOSES:

- Discard and do not use any hose that does not have an identifying serial number.
- Discard and do not use any hose that shows any sign of damage:
 - to the coloured molded plastic coating;
 - where the spiral windings are exposed;
 - where the spiral windings are damaged or broken;
 - where there is damage to the swaged metal ends;
 - do not allow any hose to be kinked or knotted.
- Hoses which have been kinked or knotted will have suffered damage and must be discarded.
- Do not allow heavy objects to fall on, rest on, or roll over the hoses.
- Do not allow hoses to be subjected to temperatures higher than 60°C.
- Discard and do not use any hose which has been subjected to heat or fire.
- Do not bend the hose tighter than the minimum bend radius of the hose or it will be kinked.
- Do not exceed the maximum working pressure of the hoses.
- Only use the hoses for their intended purpose – for use with Boltight hydraulic equipment.
- After use check the hoses for damage, wipe to remove dirt and oil, refit dust caps and prepare for storage.
- When not in use store the hoses in a safe place where they cannot easily be damaged.
- Do not mix the coloured hoses. The end fittings /quick disconnect couplings have different pressure ratings.
- Never move hose end connectors or quick disconnects from one colour hose to another.
- All Boltight tools are marked with maximum operating pressure - ensure tools are compatible with the hoses you are using.
- Never use the hoses as a handle to carry or pick up the bolt tensioning tools.

If in doubt contact your representative for further information.

1.5 HYDRAULIC BOLT TENSIONING TOOLS

Maximum pressure

This can be found directly on the tensioner, GA drawing of the tensioner or pressure vs load graph - see section 4 for more information The bolt being tensioned may have a maximum load less than that generated by the tensioner at maximum working pressure. The operator needs to confirm and check what the maximum pressure is for the particular application being tensioned.

Information on the maximum pressure for the tensioner can be found in **Section 4**.

Do not exceed the maximum working pressure.

The operational pressure for an application is often not limited by the stud material yield. The tooling has been issued with a pressure/load certificate. Never exceed the tested load or pressure, whichever is lower. See **Section 4** for more information on pressure vs initial bolt stress graph.

Maximum stroke

Observe the maximum piston stroke.

A highly visible red line indicates when the piston has reached its maximum stroke. The pump should be stopped as soon as the red indicator can be seen. If the tool exceeds maximum piston stroke then the stroke limiting valve will activate to vent the oil internally. This protects the seals and cylinder body from accidental over stroke.

STROKE INDICATOR



1.6 PERSONAL PROTECTIVE EQUIPMENT (PPE)

When using bolt tensioning tools the operator should ensure that they are wearing the correct Personal Protective Equipment (PPE).



This equipment includes (but is not limited to):

- eye protection;
- gloves;
- overalls;
- hard hat;
- steel toe-capped boots or shoes;
- any other site specific PPE required.

SECTION 2 – OPERATING INSTRUCTIONS

Introduction

A hydraulic bolt tensioner is simply an annular jack with a hollow bore. Much like a jack, a hydraulic pushing force is generated, however instead of lifting a heavy object the force is transferred into stretching a bolt. To allow the transfer of force into the bolt a hydraulic tensioner utilises a threaded puller, bridge and nut rotating socket to effectively transfer and lock in the tensioned load within a joint.

Unlike conventional tightening methods bolt tensioning does not use torque and does not require any forceful turning of the nut or bolt, like impact wrenches, flogging spanners or hydraulic torque wrenches. All of these methods have one common limitation, **FRICTION**.

Friction accounts for up to 80% of the energy lost when torque tightening a joint, giving only 20% transferable energy for bolt tension.

Bolt tensioning tools can be grouped together to enable multiple bolts to be tightened simultaneously, to the same high and accurate pre-load. This is particularly useful when compressing gaskets in pipeline or pressure vessel flanged connections. The high load developed from the multiple bolt tensioning tools, is evenly distributed around the joint causing the gasket to flow into the surface irregularities of the flange giving a much better seal.


Flexible hoses with self sealing quick connect couplings are used to group the bolt tensioning tools together to form a hydraulic ring main. The ring main and tensioning tools are pressurised using an air driven pump working from a compressed air supply or an electric pump.

2.1 RECOMMENDED PRACTICES

To obtain the best results from your hydraulic bolt tensioning equipment you should follow the operating instructions given in the following pages carefully. Please observe the instructions given below.

DO NOT try to pressurise the hydraulic load cell unless it is properly seated on its bridge and the puller has been correctly fitted onto the bolt to be tightened or released. If the hydraulic load cell is pressurised when it is not seated on a bridge or when a puller is not fully engaged the hydraulic load cell may be damaged beyond safe or repairable use.

DO NOT try to use the pump to push the piston out of the hydraulic load cell at zero load, by more than **6mm** before it comes into contact with the puller. If you do want to push out the piston by more than **6mm** do so only in **6mm** stages and ensure the piston is brought back into alignment with the hydraulic load cell by use of the puller at the end of each **6mm** of travel. Failure to do so may cause the piston to score the hydraulic load cell which may be so badly damaged that it cannot be used again.



IMPORTANT NOTICE

The images shown in this section of the manual show tools with only one hydraulic connection. However the instructions equally apply to having two hydraulic connections.

Remember that if your tool has two hydraulic connections it is necessary to fit a blank plug to the quick connect coupling/nipple before applying any pressure.

2.2 MAIN COMPONENT PARTS



1 Puller

The puller consists of an internal female thread which mates with the bolts male thread. A knurled external flange allows for ease of rotation when assembling onto the bolt and several tommy bar holes allow for additional leverage when required. The outer flange of the puller reacts on the hydraulic load cells piston to allow transfer of the load directly into the bolt.

2 Hydraulic load cell

The hydraulic load cell produces the force required to tension a bolt. High pressure hydraulic oil is delivered via up to two self sealing quick connections. Both the puller and bridge are integral parts in the delivery of hydraulic force. The puller fits within the internal bore of the load cell and the bridge is assembled within a recess. The hydraulic load cell has piston retract and piston stroke limiting technology built in.

3 Bridge

The bridge and internally mounted socket fit over the nut and bolt. The bridge acts like a pillar and reacts off the joint of the application during tensioning. Carefully designed cutouts to the rear and sides of the bridge allow for an optimised fitment between adjacent bolts and rear obstructions such as welds or machined radius on flanges. A front access window allows for socket rotation and nut wind down during tensioning.

4 Socket

The socket allows for the easy rotation and seating of a joints hexagonal nut to lock in the bolt tension load during tensioning operation. Drilled holes in the socket allow for rotation to be made via the use of tommy bars, creating ample leverage and a safe working distance from the joint.

5 Bolt

An extra length of thread must protrude through the nut for the tensioner to screw onto and apply the bolt tension. The length of the bolt is very important. Details are given in **Section 2.3 Step 1. NOTE:** Good quality bolts and nuts will make the tensioning operation quicker and more accurate.

2.3 FATIGUE LIFE

The puller of the bolt tensioning tool is subject to fatigue loading during normal operation of the equipment. The pullers provided have a fatigue life of 10,000 cycles at full operating pressure. Provision should be made to replace the pullers before 10,000 pressure cycles.

Pullers should be examined yearly for any sign of fatigue. Depending on the intended usage frequency the user is advised to determine a safe replacement interval for the pullers. If the tools are being used to support a hire operation it is important to change the pullers every 5 years.

2.4 TENSIONING A BOLT

Step 1


Ensure the joint has been assembled using the correct nuts and bolts required for tensioning.

To ensure the safe and effective use of the hydraulic bolt tensioner ensure that a minimum of 2x bolt diameters of bolt length is protruding from the surface of the joint face. Bolt protrusion in excess of 2x bolt diameter is acceptable.


It is imperative that the correct bolt length is available prior to hydraulic tensioner activation as failure to do so may result in the threads stripping off the bolt and the bolt tensioner puller.

HEALTH & SAFETY WARNING

If only a few threads protrude and an attempt is made to apply tension the bolt threads will strip and components of the tensioner could be propelled with the possibility of serious injury and may cause damage to the bolt and tensioner.



✓ **CORRECT AND SAFE**



✗ **WRONG AND DANGEROUS**


Step 2

As standard tools are supplied with a captive socket, when tensioning bolts with hexagon nuts it is common place to utilise the socket to rotate and wind down the nut so that it seats on the surface of the application locking in the load. A tommy bar is used to give assisted leverage and ensure a safe working distance.

Some tools feature a circular groove located in the bridge to allow the fitment of a socket retaining ring, this gives the option of captivating the socket within the bridge. If this option is chosen there is no need to place the socket over the nut separately to the bridge and this step can be ignored.

When using the bolt tensioner on a joint which utilises drilled round or hexagon nuts the socket can be removed. The nut can then be turned down with the corresponding sized tommy bar.

Ensure the bridge is seated on a flat and level surface and avoids any adjacent nuts or application obstructions. Ensure the bridge does not largely overhang or react off uneven surfaces.




Step 3

Place the hydraulic load cell and bridge assembly over the nut, bolt and socket.

The load cell and bridge are assembled together using set screws positioned radially on the lower outside diameter of the hydraulic load cell. The bridge and hydraulic load cell can be rotated relative to each other. This allows the self sealing quick connect hydraulic connection on the load cell to be placed in the best position for connecting the flexible hydraulic hose. On applications where space is limited above the bolt, it may be helpful to separate the bridge and the load cell, placing them individually onto the bolt.


If disassembly is required use an appropriately sized hex key to loosen the set screws. Once loose separate the bridge from the load cell. To reassemble reverse this process however do not over tighten the set screws as this will lock the bridge in place and prevent rotation.

A window in the front of the bridge allows access to the socket with a tommy bar. The bridge may have flats on each side to clear any adjacent nuts. The bridge and load cell may have an angled flat at the back to clear any obstruction behind the bolt and nut, such as the hub of a weld neck flange.



Step 4


Place the puller into the centre of the hydraulic load cell and lower until the bottom face of the puller touches the top face of the bolt. Carefully engage the puller onto the bolts mating threads by turning in a clockwise direction. If the puller becomes tight do not force it as this may be an indication of damaged threads, incorrect thread sizing or an obstruction. The puller should rotate freely, a tommy bar can also be used to rotate the puller down once the mating threads have been fully engaged.



Step 5

Continue to wind down the puller until the lower face of the pullers flange firmly contacts the top face of the hydraulic load cells piston. Excessive force is not required.

During the rotation of the puller, ensure that the bolt remains stationary as failure to do so could result in a reduced thread engagement in both the puller or application.



✓ The puller is in full contact with the top of the hydraulic load cell.




✗ The puller is not fully in contact with the top of the hydraulic load cell.

Step 6

The bolt tensioner is now locked in place and cannot fall off. The tool is now ready for the hydraulic hose to be connected.

Once the puller has been screwed down, check the thread engagement with the bolt is still correct.




Step 7

Connect the tensioner to corresponding hydraulic hose and pump unit.

Make sure the quick connect coupling is fully engaged. See **Section 1.3**.

If required re-tighten the puller into position. Open the pumps oil return to tank valve and ensure the piston does not retract further. If it does then simply wind down the puller to regain piston engagement.




Step 8

If required, fit a blanking plug to the open quick connector.

Ensure the connector is fully engaged.

Only when the second hydraulic connection has been plugged can the tool be pressurised.

See **Section 2.5** of this manual to learn how to use multiple tooling for simultaneous bolt tightening operations.



TENSIONING A BOLT – HEALTH & SAFETY

The bolt tensioning tool is now ready to be pressurised. Before proceeding read the Health & Safety Instructions given in **Section 1** of this manual then proceed as follows:

- Ensure suitable PPE has been utilised prior to pressurisation.
- Clear all personnel from the area where the bolt tensioning operation is to be performed. Position the pump a safe distance away from the bolt tensioning tools. Set up barriers and warning signs, or make other adequate arrangements to prevent unauthorised personnel from accidentally straying into the bolt tensioning area.
- Release the oil pressure immediately if any unauthorised person moves into the bolt tensioning area and especially if anyone stands in front of the puller of a bolt tensioning tool under pressure or stands in line with the long axis of a bolt being tensioned.
- Determine the correct working pressure for the bolts to be tightened. Proceed with the following operations keeping the bolt tensioning tools under pressure for the minimum time necessary to complete the bolt tightening operation.

Step 9

Utilising the pressure load information as shown in **Section 4 – Technical Information**, slowly activate the hydraulic pump to raise the hydraulic pressure within the tensioner. During activation the piston will move out of the load cell as the bolt is stretched and the joint is compressed.


DO NOT exceed the maximum piston stroke. This is indicated by a red line around the piston.

DO NOT exceed the maximum pressure for the tool.

DO NOT stand in line with the axis of the bolt and the puller of the bolt tensioning tool when it is under pressure.



A highly visible red line indicates when the piston has reached its maximum stroke. Stop the pump as soon as the red indicator can be seen. If the tool is over-stroked the valve will activate and oil will be vented internally to prevent damage to the tensioner.



Ensure the stroke of the piston is observed during pressurisation. If the maximum piston stroke indicator becomes visible, **STOP** the pump and wind down the nut as shown in **Step 10**.

If a second pull of the joint is required reset the tensioner and wind the puller back down as shown in **Step 7**.

STROKE LEVEL
INDICATOR



Step 10

Use a tommy bar to turn the socket clockwise, to tighten the nut.

Insert the tommy bar through the window in the bridge until it engages with the furthest right hole in the socket.

Turn the socket clockwise as far as it will go. If the tommy bar comes into contact with the bridge, remove it and engage the next furthest right hole in the socket.

Continue to rotate the socket until the nut is firmly seated on the face of the application.



Step 11


Once the desired tensioning pressure has been reached and the nut has been fully seated on the surface of the joint the pressure within the tool can be released, locking the load within the joint.

Release the pressure by slowly opening the pressure release valve on the hydraulic pump.

Use the tommy bar to tighten the puller until the piston is fully returned into the load cell.

If the tool supplied has an automatic piston return, the piston will return automatically once the oil pressure release valve is opened.

Once the piston is all the way down remove the hydraulic hose.




Step 12

Remove the puller from the joint by rotating anti-clockwise. Use a tommy bar for added leverage if required.




Step 13

Remove the hydraulic load cell and bridge.



Step 14

If it is not retained in the bridge,
remove the socket.



2.5 DE-TENSIONING A BOLT

Step 1

De-tensioning of a bolt follows many of the steps as shown in the previous section. There are however a few key differences in the process which are explained within the following section.


First visually inspect the bolts to be de-tensioned. To ensure the safe and effective use of the hydraulic bolt tensioner ensure that a minimum of 2x bolt diameter of bolt length is protruding from the surface of the joint face. Bolt protrusion in excess of 2x bolt diameter is acceptable.

It is imperative that the correct bolt length is available prior to the hydraulic tensioner activation as failure to do so may result in the threads stripping off the bolt and the bolt tensioner puller.


Next ensure that the threads are clean and have not been damaged. Any damage to the threads should be rectified with a thread file or die nut before attempting to assemble the hydraulic bolt tensioning tool onto the bolt.

HEALTH & SAFETY WARNING

If only a few threads protrude and an attempt is made to apply tension the bolt threads will strip and components of the tensioner could be propelled with the possibility of serious injury and may cause damage to the bolt and tensioner.



✓ **CORRECT AND SAFE**



✗ **WRONG AND DANGEROUS**


Step 2

Place the socket over the nut to be untightened. When tensioning bolts with hexagon nuts it is common place to utilise the socket to rotate and wind down the nut so that it seats on the surface of the application locking in the load. A tommy bar is used to give assisted leverage and ensure a safe working distance.

On some tools there is a circular groove in the Bridge to fit a socket retaining ring, which gives the option of captivating the Socket within the Bridge. If this option is chosen there is no need to place the Socket over the nut separately to the Bridge and this step can be ignored.

When using the bolt tensioner on an joint which utilises drilled round or hexagon nuts the socket can be removed. The nut can then be turned down with the corresponding sized tommy bar.

Ensure the bridge is to be seated on a flat and level surface and avoids any adjacent nuts or application obstructions. Ensure the bridge does not largely overhang or react off uneven surfaces.




Step 3

Place the hydraulic load cell and bridge assembly over the nut, bolt and socket.

The hydraulic load cell and bridge are assembled together using set screws positioned radially on the lower outside diameter of the hydraulic load cell. The bridge and hydraulic load cell can be rotated relative to each other. This allows the self sealing quick connect hydraulic connection on the load cell to be positioned in the best position for connecting the flexible hydraulic hose. On applications where space is limited above the bolt, it may be helpful to separate the bridge and the load cell, placing them individually onto the bolt.


If disassembly is required use an appropriately sized hex key to loosen the set screws. once loose separate the bridge from the load cell. To reassemble reverse this process however do not over tighten the set screws as this will lock the bridge in place and prevent rotation.

A window in the front of the bridge allows access to the socket with a tommy bar. The bridge may have flats on each side to clear any adjacent nuts. The bridge and load cell may have an angled flat at the back to clear any obstruction behind the bolt and nut, such as the



Step 4

Place the puller into the centre of the hydraulic load cell and lower until the bottom face of the puller touches the top face of the bolt. Carefully engage the puller onto the bolts mating threads by turning in a clockwise direction. If the puller becomes tight do not force it as this may be an indication of damaged threads, incorrect thread sizing or an obstruction. The puller should rotate freely, a tommy bar can also be used to rotate the puller down once the mating threads have been fully engaged.




Step 5

IMPORTANT: Now turn back the puller at least one full revolution. This operation ensures the piston can retract into the load cell when the bolt becomes free and needs to return to its original length.

If this step is missed the load retained in the bolt will be transferred from the nut to the puller during the de-tensioning operation which in turn will lock the puller in place so that it cannot be removed.

In the event of this happening , re-tighten the bolt using the bolt tensioner, tighten the nut using the tommy bar and release the oil pressure. The puller can then be wound back the one full turn necessary to avoid this situation arising again.

The tool is now ready for the hydraulic hose to be connected.




Step 6

Connect the tensioner to corresponding hydraulic hose and pump unit.

Make sure the quick connect coupling is fully engaged.

DO NOT tighten the puller with the tommy bar.




Step 7

If applicable fit a blank nipple to the quick connect coupling.

Ensure the connector is fully engaged.

Only when the second hydraulic connection has been plugged can the tool be pressurised.



DE-TENSIONING A BOLT – HEALTH & SAFETY

The bolt tensioning tool is now ready to be pressurised. Before proceeding read the Health & Safety Instructions given in **Section 1** of this manual then proceed as follows:

- Ensure suitable PPE has been utilised prior to pressurisation.
- Clear all personnel from the area where the bolt tensioning operation is to be performed. Position the pump a safe distance away from the bolt tensioning tools. Set up barriers and warning signs, or make other adequate arrangements to prevent unauthorised personnel from accidentally straying into the bolt tensioning area.
- Release the oil pressure immediately if any unauthorised person moves into the bolt tensioning area and especially if anyone stands in front of the puller of a bolt tensioning tool under pressure or stands in line with the long axis of a bolt being tensioned.
- Determine the correct working pressure for the bolts to be tightened. Proceed with the following operations keeping the bolt tensioning tools under pressure for the minimum time necessary to complete the bolt tightening operation.


Step 8

Utilising the pressure load information as shown in **Section 4 – Technical Information**, slowly activate the hydraulic pump to raise the hydraulic pressure within the tensioner. During activation the piston will move out of the hydraulic load cell as the bolt is stretched and the joint is compressed.

DO NOT exceed the maximum piston stroke.
This is indicated by a red line around the piston.

DO NOT exceed the maximum pressure for the tool.

DO NOT stand in line with the axis of the bolt and the Puller of the bolt tensioning tool when it is under pressure.



A highly visible red line indicates when the piston has reached its maximum stroke. Stop the pump as soon as the red indicator can be seen. If the tool is over stroked the valve will activate and oil will be vented internally to prevent damage to the tensioner.

Ensure the stroke of the piston is observed during pressurisation. If the maximum piston stroke indicator becomes visible, **STOP** the pump and wind down the nut as shown in **Step 10**.

If a second pull of the joint is required reset the tensioner and wind the puller back down as shown in **Step 7**.




Step 9

Use a tommy bar to turn the socket anti-clockwise, to loosen the nut.

Insert the tommy bar through the window in the bridge until it engages with the hole the furthest left in the socket.

Turn the socket anti-clockwise. If the tommy bar comes into contact with the bridge, remove it and engage the next hole in the socket.

Continue turning the socket until the nut has been undone one full turn. Do not let the nut come into contact with the puller.



Step 10

Once the desired tensioning pressure has been reached and the nut has been released from the surface of the joint. The pressure within the tool can be released.

Release the pressure by slowly opening the pressure release valve on the hydraulic pump.

Use the tommy bar to tighten the puller until the piston is fully returned into the load cell. Once the piston has fully retracted, the tensioner can be removed from the joint.

NOTE: If the tool supplied has an automatic piston return, the piston will return automatically once the oil pressure release valve is opened.




Step 11

Remove the puller from the joint by rotating anti-clockwise. Use a tommy bar for added leverage if required.




Step 12

Remove the hydraulic load cell and bridge.



Step 13

If it is not retained in the bridge, remove the socket.



2.6 SIMULTANEOUS BOLT TENSIONING

Ensure you have read and understood both the bolt tensioning and de-tensioning methods as shown in the previous sections prior to conducting a simultaneous bolt tensioning operation.

Simultaneous bolt tensioning improves the speed and efficiency when performing a tensioning operation on a multi stud application. Boltight recommend a minimum of 25% bolt coverage when tensioning a joint, with 100% coverage giving the largest advantage in speed and accuracy. When it is not possible to fit 1 tensioner per bolt, Boltight recommend reducing to 50% bolt coverage.


When tensioning bolts simultaneously the tensioning procedure is the same as tensioning a single bolt, however the hydraulic hose setup is different. The hydraulic hoses need to be interconnected in a pattern to allow effective oil flow and oil feed into each hydraulic tensioner simultaneously from a common pump unit.

The following section demonstrates examples of commonly utilised link hose setup. There are multiple ways hoses can be connected however the common objective is to ensure that oil is safely supplied to each tool simultaneously. Ensure all hose safety instructions are understood and that the minimum bend radius is utilised when selecting the hose setup.

If in doubt contact your representative for further information.


Interconnecting hose arrangement

The interconnecting hose arrangement is the most commonly recommended hose setup. It is well suited for multiple tensioning tools in large groups. As the setup is 100% external, forming a hydraulic ring-main, it allows easy manual piston reset or quick reset for auto return tensioners.




Daisy chain arrangement

The daisy chain arrangement is an affordable method of connecting multiple tools. It is best for simplicity, as only one type of hose needs to be specified, however with this setup oil must pass through every hydraulic cylinder increasing the resistance for manual piston reset or increasing the time reset takes for auto return tensioners.



Manifold arrangement

The manifold arrangement is well suited to small groups of tensioning tools, particularly where the tensioner coverage pattern is spread out.



SECTION 3 – MAINTENANCE & STORAGE

Introduction

A hydraulic bolt tensioning tool will provide many years of trouble free service if used, maintained and stored correctly.

3.1 STORAGE

Each tool is surface treated before leaving the factory. This provides a degree of corrosion protection but additional protection should be applied when the tools are to be stored for any period of time. It is recommended that, before storage, the tools should be dismantled into their four major components:

- Puller
- Hydraulic Cylinder
- Bridge Assembly
- Socket

Each of these items should be checked for damage and if OK, lightly oiled and then reassembled. The reassembled tool must have the piston returned to the zero stroke position and the hydraulic connection must have its plastic protective cap fitted. The hydraulic bolt tensioner should be stored upright in a clean, dry environment.

Very little maintenance is required for a bolt tensioning tool. The only items which may require changing will be the seals and quick connect fittings.

3.2 MAINTENANCE - CHANGING THE SEALS


Each bolt tensioning tool has an inner and an outer seal set. Each seal set consists of a rubber "O" ring and an elastomeric seal. If the seals are damaged or badly worn, the complete set ("O" ring and seal) must be changed. It is recommended that both inner and outer sets are changed at the same time.

To change the seals, the piston must be withdrawn from the load cell. If the seals are not badly damaged this may be achieved by carefully blowing compressed air into the load cell through the quick connect nipple. All applicable Health & Safety precautions relating to the use of compressed air must be observed. In addition suitable safe provision must be made to catch the piston and any escaping oil when it leaves the load cell.

If the seal damage is too great to allow air to be used, the piston may be removed by making a simple piston extraction tool from a bar of steel. The bar must be drilled with two holes to align with the threaded holes found in the top of the piston. Two screws can be used to secure the bar to the piston. The piston can then be pulled from the body using the bar.

The seals are self lubricating and will always exhibit a small amount of oil around the inner and outer edges of the piston. The presence of a small amount of a small volume of oil around the piston is NOT a signal the seals need to be changed. The oil lubricates the load cell wall, reduces the force required to return the piston and helps to prevent corrosion. After extensive use as much as 5 ml of oil may be present around the piston. Simply wipe away any oil when the tools have been used. The seals will need to be changed only if the tool will not pressurise or a very large volume of oil escapes whilst the oil pressure is being increased, or if the tools will not hold pressure.

3.3 PARTS BREAKDOWN



| Item no. | Description | Part no. | Qty. |
|----------|------------------------|----------|------|
| 1 | Puller | | 1 |
| 2 | Piston | | 1 |
| 3 | Indicator Ring | | 1 |
| 4 | Seal Kit | | 1 |
| 5 | Load Cell | | 1 |
| 6 | Male to Male Adaptor | | 1 |
| 7 | Male quick connector | | 1 |
| 8 | Bridge Retaining Screw | | 1 |
| 9 | Bridge | | 1 |
| 10 | Socket | | 1 |
| 11 | Snap Ring | | 1 |

3.4 MAINTENANCE – CHANGING THE INNER PISTON SEAL


The old seal set must be removed by cutting through the seal with a knife. The “O” ring can be removed by cutting or by levering it out. Both items should be discarded. Lubricate the “O” ring with grease. Ensure the seal groove is clean.




-
- Place the piston on a clean surface.
 - Insert the rubber “O” ring into the seal groove.




-
- Fit the “O” ring into the seal groove.




-
- Pack the “O” ring with grease.




-
- Insert the green pastic seal into the seal groove.
 - Make sure the chamfer is at the top.



-
- Work the seal into the groove using hand force only.



-
- The seal will snap into the seal groove.



-
- Wipe away any excess grease.
-

3.5 MAINTENANCE – CHANGING THE OUTER PISTON SEAL


The old seal set must be removed by cutting through the seal with a knife. The “O” ring can be removed by cutting or by levering it out. Both items should be discarded. Lubricate the “O” ring with grease. Ensure the seal groove is clean.



-
- Place the piston on a clean surface.
 - Insert the rubber “O” ring into the seal groove.



-
- Stretch the “O” ring until it snaps into the seal groove.




-
- Pack the “O” ring with grease.




-
- Insert the green pastic seal into the seal groove.
 - Make sure the chamfer is at the top.



-
- Stretch the seal over the outer lip of the piston by working around both sides of the piston simultaneously.




- Work the seal into the groove using hand force only



- Wipe away any excess grease.

3.6 MAINTENANCE – FITTING THE PISTON


The easiest and safest method of fitting a piston into any of our T Series tensioners is by using a test block such as the one shown below. This can be easily manufactured with a steel base threaded through the centre to fit the correct stud bolt for the tensioner in question. Assuming that the test block has been manufactured from the appropriate grade of steel, it can also be used to pressure test the tools once the pistons are fitted. Alternatively the piston could be fitted using an application bolt on a flange that is to be tensioned. The principal remains the same.




- Make sure the cylinder and piston are clean and free from foreign objects and dirt.
- Lubricate the cylinder walls and the seals of the piston with hydraulic oil.



- Assemble the tool onto the bolt as normal; the bridge followed by the load cell.



- Ensure that you fit an open quick connect coupling to the hydraulic connection to enable air to be expelled from the load cell as the Piston is pushed in.



- Place the piston over the load cell.
- Ensure that the piston is correctly aligned with the load cell.



- Wind the puller down onto the bolt until it is in contact with the piston.
- Check that the piston is aligned correctly with the load cell.



- Using a tommy bar, gently wind the puller down the bolt, easing the piston into the load cell. This should not require much force.
- The seals can be easily damaged if the Piston is not aligned correctly with the load cell.



- Once the puller is fully engaged, the piston is fitted.
- Remove the open quick connect coupling.
- The seals can now be energised and the tool tested as it stands. (**See Section 3.4**)



- The piston is now fitted correctly into the load cell.

3.7 MAINTENANCE - ENERGISING THE SEALS

After fitting new seals and before using the tool the new seals need to be energised. Ensure the product instruction manual has been read and that all safety instructions are correctly followed:

- Make sure the piston is fully returned into the hydraulic load cell.
- Assemble the tensioner to an appropriate test stud, test assembly, or an actual bolt to be tensioned.
- Wind back the puller **ONE FULL TURN**
- Please see **Section 2** for installation procedure.
- Connect the hydraulic tensioner to the pump via suitable hydraulic hose connection.
- Air and oil may escape from the seals during this operation and the pressure gauge may indicate rising and falling pressure at each stroke of the pump.
- If the seals have been properly fitted the seals will quickly energise. Any leakage from the seals will stop and pressure will start to be generated in the tool.
- Ensure the Puller has been fully wound down so that it is in contact with the piston and ensure the piston has been returned to 0mm stroke.
- Activate the pump and allow the tool pressure to raise to the tools maximum working pressure of 1000bar (**DO NOT EXCEED THIS PRESSURE**).
- Once 1000bar has been reached hold the pressure constant for 2 minutes. Note it is normal to see a small drop in pressure as the seal re-seats. If this happens top up the pressure to 1000bar.
- Once the tool has been taken to full pressure the seals should be energised and the tensioner is ready for use.
- If the seals will not energise, the tool must be taken apart again because the seals have not been correctly fitted. The seals may not energise if the pump is unable to deliver oil quickly enough.
- Disassemble the tools as shown in **Section 2**.

3.8 MAINTENANCE – FITTING A QUICK CONNECTOR (WITHOUT A BONDED SEAL)

Fitting either the quick connect nipple or coupling, can be achieved by following the simple steps shown below.



-
- Check the internal and external threads are clean and free from damage.



-
- Screw the adaptor into the hydraulic load cell.
 - The adaptor is identical at each end so it does not matter which end is inserted into the load cell.



-
- Screw the Nipple or Coupling onto the adaptor.



-
- Using a spanner, firmly tighten the nipple or coupling onto the adaptor.
-

3.9 MAINTENANCE – FITTING A QUICK CONNECTOR (WITH A BONDED SEAL)


To fit a quick connector that requires a bonded seal the steps are the same as **Section 3.4**. However the user must ensure that a bonded washer is located between the load cell and the adaptor. Apply Loctite 542 to the adaptor where shown.




3.10 MAINTENANCE – REMOVING AND FITTING THE BRIDGE

The bridge and the load cell can be joined together to make one piece. When using the tensioner it is sometimes advantageous to work with three separate parts, however when it is better for the load cell and the bridge to be joined, bridge retaining screws are used. Depending on the tensioners size, two or three bridge retaining screws are used. The screws are socket head screws with dog Points. They are located in radial drilled and tapped holes near the top of the bridge.

The screws remain in the bridge and the dog point can be advanced into the groove in the recess, found at the base of the load cell. A hexagon key is used to advance or withdraw the bridge retaining screws working from the inside of the bridge. It is not necessary to remove the screws for the bridge and load cell to be separated. The screws need only be withdrawn into the Bridge wall 2 - 3mm to disengage the dog point from the groove.



When refitting the bridge, the bridge retaining screw need only be advanced enough for the dog points to locate into the groove in the hydraulic load cell. If they are fully advanced and tightened, the bridge will be locked into the load cell which is not recommended. If the screws are advanced but not tightened, the bridge and the load cell will be permanently joined but the two components will rotate relative to each other. This can be useful as the load cell can be rotated until the quick connectors are in the best position for the flexible hoses to be connected whilst the window in the bridge is in the best position for access to the nuts with a tommy bar.



SECTION 4 – TECHNICAL INFORMATION

4.1 OIL PRESSURE CALCULATIONS

The formula widely used to calculate the oil pressure to be used with a bolt tensioning tool is given below along with definitions of the terms used:

Bolt load

Residual Bolt Load required when the tensioning operation is complete.

Tensioning force

The load that will be applied by the bolt tensioner during the tensioning operation.



Load transfer factor

The ratio of **tensioning force** to **bolt load**.

$$\text{Load transfer factor} = \frac{\text{Tensioning force}}{\text{Bolt load}} = 1.01 + \frac{\text{Bolt diameter (mm)}}{\text{Grip length (mm)}}$$

If the **Load transfer factor** calculates to less than 1.10 then use 1.10
Tensioning force = Bolt Load × Load Transfer Factor

$$\text{Oil Pressure (bar)} = \frac{10 \times \text{Tensioning Force (Newtons)}}{\text{Tool Pressure Area (mm}^2\text{)}}$$



Always check that the tensioning force will not exceed 95% of the yield strength of the bolt material. If it does, the grip length of the bolt must be increased. Please contact your representative for advice on this.

4.2 PRESSURE LOAD GRAPHS


Oil pressure graphs are always provided with each hydraulic tensioner and are specific to the size of the hydraulic tensioner supplied.

One graph will show the theoretical tensioning force developed by the tool against the oil pressure applied.

The graphs included with this manual show the initial bolt stress developed by the tool against the oil pressure applied for each bolt size. This graph is provided to assist to check that the tensioning force does not exceed 95% of the yield strength of the bolt material.


Users who require highly accurate residual bolt stresses should perform a bolt extension measurement before and after tensioning. In this way residual bolt stresses can be calculated from the actual bolt extensions measured.

4.3 TOOL SPECIFICATION AND DIMENSIONS





Do not use an oil pressure which will result in an initial bolt stress in excess of 95% of the minimum yield stress of the bolt material.

Refer to **pages 39 to 43** for specific tooling specification & dimensions.



This drawing and the design is the property of Boltight Ltd. and must not be copied or disclosed to any third party without the written consent of the company

THD - THREAD DIAMETER



The drawing and the design is the property of Bolight Ltd. and must not be copied or disclosed to any third party without the written consent of the company

**Tools are designed to following
Imperial Nut Dimensions**

| Imperial Thread Sizes | NAF | | NH | |
|-----------------------------|-------|-------|-------|-------|
| | mm | inch | mm | inch |
| 4 in | 155.6 | 6.125 | 101.6 | 4.000 |
| 3-3/4 in | 146.1 | 5.750 | 95.3 | 3.750 |
| 3-1/2 in | 136.5 | 5.375 | 88.9 | 3.500 |
| 3-1/4 in | 127.0 | 5.000 | 82.6 | 3.250 |
| 3 in | 117.5 | 4.625 | 76.2 | 3.000 |
| 2-3/4 in | 108.0 | 4.250 | 69.9 | 3.750 |
| 2-1/2 in | 98.4 | 3.875 | 63.5 | 2.500 |
| 2-1/4 in | 88.9 | 3.500 | 57.2 | 2.250 |
| 2 in | 79.4 | 3.125 | 50.8 | 2.000 |
| 1-7/8 in | 74.6 | 2.938 | 47.6 | 1.875 |
| 1-3/4 in | 69.9 | 2.750 | 44.5 | 1.750 |
| 1-5/8 in | 66.5 | 2.620 | 41.3 | 1.625 |
| 1-1/2 in | 60.3 | 2.375 | 38.1 | 1.500 |
| 1-3/8 in | 55.6 | 2.188 | 34.9 | 1.375 |
| 1-1/4 in | 50.8 | 2.000 | 31.8 | 1.250 |
| 1-1/8 in | 46.0 | 1.812 | 28.6 | 1.125 |
| 1 in | 41.3 | 1.625 | 25.4 | 1.000 |
| 7/8 in | 36.5 | 1.438 | 22.2 | 0.875 |
| 3/4 in | 31.8 | 1.250 | 19.1 | 0.750 |

**Tools are designed to following
Metric Nut Dimensions**

| Metric Thread Sizes | NAF | | NH | |
|---------------------------|-----|------|-----|------|
| | mm | inch | mm | inch |
| M100 | 145 | 5.71 | 100 | 3.94 |
| M95 | 135 | 5.31 | 95 | 3.74 |
| M90 | 130 | 5.12 | 90 | 3.54 |
| M85 | 120 | 4.72 | 85 | 3.35 |
| M80 | 115 | 4.53 | 80 | 3.15 |
| M76 | 110 | 4.33 | 76 | 2.99 |
| M72 | 105 | 4.13 | 72 | 2.83 |
| M68 | 100 | 3.94 | 68 | 2.68 |
| M64 | 95 | 3.74 | 64 | 2.52 |
| M60 | 90 | 3.54 | 60 | 2.36 |
| M56 | 85 | 3.35 | 56 | 2.20 |
| M52 | 80 | 3.15 | 52 | 2.05 |
| M48 | 75 | 2.95 | 48 | 1.89 |
| M45 | 70 | 2.76 | 45 | 1.77 |
| M42 | 65 | 2.56 | 42 | 1.65 |
| M39 | 60 | 2.36 | 39 | 1.54 |
| M36 | 55 | 2.17 | 36 | 1.42 |
| M33 | 50 | 1.97 | 33 | 1.30 |
| M30 | 46 | 1.81 | 30 | 1.18 |
| M27 | 41 | 1.61 | 27 | 1.06 |
| M24 | 36 | 1.42 | 24 | 0.94 |
| M22 | 32 | 1.26 | 22 | 0.87 |
| M20 | 30 | 1.18 | 20 | 0.79 |

NOTES

Boltight always recommend to have at least 1xTHD stud protrusion above the nut. If not please make sure the correct amount of thread engagement is achieved before operating.

4.4 TECHNICAL INFORMATION – IMPERIAL BOLT SIZES

| Tool No. | Bolt Diameter | Hydraulic Area | Max. Stroke | Max. Load | | TOD | | TH | | |
|----------|---------------|-----------------|-------------|-----------|-------|-----|------|-----|------|--|
| | | mm ² | mm | kN | klbf | mm | inch | mm | inch | |
| T21 | 3/4 | 1555 | 12 | 233 | 52.4 | 73 | 2.9 | 102 | 4.0 | |
| | 7/8 | | | | | | | | | |
| | 1 | | | | | | | | | |
| | 1-1/8 | | | | | | | | | |
| T22 | 1-1/8 | 2884 | 15 | 433 | 97.3 | 105 | 4.1 | 131 | 5.2 | |
| | 1-1/4 | | | | | | | | | |
| | 1-3/8 | | | | | | | | | |
| | 1-1/2 | | | | | | | | | |
| T23 | 1-1/2 | 5271 | 15 | 791 | 177.8 | 136 | 5.4 | 147 | 5.8 | |
| | 1-5/8 | | | | | | | | | |
| | 1-3/4 | | | | | | | | | |
| | 1-7/8 | | | | | | | | | |
| | 2 | | | | | | | | | |
| T24 | 2 | 8445 | 15 | 1267 | 284.8 | 172 | 6.8 | 168 | 6.6 | |
| | 2-1/4 | | | | | | | | | |
| | 2-1/2 | | | | | | | | | |
| T25 | 2-1/2 | 12197 | 15 | 1830 | 411.4 | 200 | 7.9 | 188 | 7.4 | |
| | 2-3/4 | | | | | | | | | |
| | 3 | | | | | | | | | |
| T26 | 3 | 16682 | 15 | 2502 | 562.5 | 235 | 9.3 | 212 | 8.4 | |
| | 3-1/4 | | | | | | | | | |
| | 3-1/2 | | | | | | | | | |
| T27 | 3-1/2 | 17530 | 15 | 2629 | 593.3 | 245 | 9.7 | 227 | 8.9 | |
| | 3-3/4 | | | | | | | | | |
| | 4 | | | | | | | | | |

[illegible]

4.5 TECHNICAL INFORMATION – METRIC BOLT SIZES

| Tool No. | Bolt Diameter | Hydraulic Area | Max. Stroke | Max. Load | | TOD | | TH | |
|----------|---------------|----------------|-------------|-----------|-------|-----|------|-----|------|
| | | mm² | mm | kN | klbf | mm | inch | mm | inch |
| T21 | M16 | 1555 | 12 | 233 | 52.4 | 73 | 2.9 | 102 | 4.0 |
| | M20 | | | | | | | | |
| | M22 | | | | | | | | |
| | M24 | | | | | | | | |
| | M27 | | | | | | | | |
| T22 | M27 | 2884 | 15 | 433 | 97.3 | 105 | 4.1 | 131 | 5.2 |
| | M30 | | | | | | | | |
| | M33 | | | | | | | | |
| | M36 | | | | | | | | |
| | M39 | | | | | | | | |
| T23 | M39 | 5271 | 15 | 791 | 177.8 | 136 | 5.4 | 147 | 5.8 |
| | M42 | | | | | | | | |
| | M45 | | | | | | | | |
| | M48 | | | | | | | | |
| | M52 | | | | | | | | |
| T24 | M52 | 8445 | 15 | 1267 | 284.8 | 172 | 6.8 | 168 | 6.6 |
| | M56 | | | | | | | | |
| | M64 | | | | | | | | |
| T25 | M64 | 12197 | 15 | 1830 | 411.4 | 200 | 7.9 | 188 | 7.4 |
| | M72 | | | | | | | | |
| | M76 | | | | | | | | |
| T26 | M76 | 16682 | 15 | 2502 | 562.5 | 235 | 9.3 | 212 | 8.4 |
| | M80 | | | | | | | | |
| | M90 | | | | | | | | |
| T27 | M90 | 17530 | 15 | 2629 | 593.3 | 245 | 9.7 | 227 | 8.9 |
| | M95 | | | | | | | | |
| | M100 | | | | | | | | |

