

STRAIGHT PIN

DIMENSION SHEET

ENGLISH

Company:	Contact person:
City / State:	
Country: Fax:	_ Email:
○ Order ○ Inquiry Quantity: pcs	Measured by:
Machine make & model:	
Machine Serial No:	Original pin part number:
Pin location on machine:	



GREASING



LOCKING RING









STRAIGHT PIN

DIMENSION SHEET

PIVOT DIMENSION

- 3.0 Original pin diameter. The diameter is usually an standard axle diameter. As a service Expander System helps to choose a suitable tolerance for the application.
- 3.1 Measure the distance between the outside edges of the mounting lugs. Measuring accuracy +/- 1 mm (+/- 0,04").
- 3.2 Measure the width of respective mounting lug. Measuring accuracy +/-1mm (+/- 0,04").
- 3.4 Fill in the original diameters of the holes of the mounting lugs (bushings removed if applicable). If the holes are more than 1,5 mm (0,06") worn measure the maximum and minimum diameters of the worn holes. Measuring accuracy +/- 0,2 mm (+/- 0,008").
- 3.5 If there are obstacles within 100 mm (4") from the outside of respective mounting lug, indicate type of obstacle (moving, fixed or hoses).
- 3.51 If obstacles indicated in 3.5, measure the distance between respective outside edge of mounting lug and obstacle. Measuring accuracy +/-1 mm (+/- 0,04").

GREASING

- 5.0 Indicate the grease distribution of the pivot. A=external greasing.
 - B= greasing through pin (one outlet centred between the inner edges of the lugs), C= greasing through pin (two outlets).
- 5.1 If B, indicate from which side the pivot is greased.
- 5.2 If C, measure the greasing outlet distance from respective outside edge of mounting lug. Measuring accuracy +/-1 mm (+/- 0,04").

LOCKING RING

- 6.0 If there is no locking ring please mark "No locking ring". If there is a locking ring, indicate on which side the ring is situated and proceed with 6.2, 6.3 and 6.5.
- 6.2 Measure locking ring inner diameter. Measuring accuracy +/- 0,5 mm (+/- 0,02").
- 6.3 Measure locking ring outer diameter. Measuring accuracy +/-1mm (+/- 0,04").
- 6.5 Measure locking ring width. Measuring accuracy +/-1 mm (+/- 0,04").



For stepped pins, please use the dimension sheet for stepped pins.

Contact your nearest Nord-Lock Group office or Expander Systemrepresentative for support, alternatively call:Expander System SwedenPhone: +46 (0)120-299 00Phone (toll free): +1 888 935-3884

